


FHE After Sales Service & Support (AU)
Phone: 1300887055
Spares Email: spares@fedservices.com.au

FHE After Sales Service & Support (NZ)
Phone: 09 415 6471
Service Email: service@fedproducts.co.nz

SN-128F PARTS LIST

Item		FHE Part Code	Description	Remark
1		02.0.0115-00	Front Ventilation Window Panel T0.8*618.1*471.3	
2		04.0.0112-00	Plastic Ventilation Window	
3*		54.0.0043-00	Control Panel Assembly	
4		04.2.0026-00	Door Black	
5*		08.1.0025-00	Condensation Sensor 1000mm	
6*		08.0.0135-01	PC Board PC-508	08.0.0135-01 is replaceable with 08.0.0135-00; the reverse is not.
7*		06.1.0002-00	Motor YZ7-20 7/38W 220V 50HZ	
8*		06.0.0002-00	Condenser Air-cooled 80A	
9*		NF7MLX	Compressor NF7MLX 187~254V/50/60HZ/R404 06.2.0003-00	
10*		08.7.0064-00	Reducer 220V/50Hz SHBM008207 80W Sigma	
11*		06.6.0020-00	Floating Ball Valve DN15WK-T	
12*		08.1.0021-00	Water Level Sensor Electronic	
13		04.0.0078-00	Water Tank-258	
14		07.0.0071-00	Ice Drill ϕ 44.6*302mm	
15		07.0.0023-00	Ice Blade ϕ 23.8 15 Tooth	
16*		13.2.0001-00	Ice Outlet Nozzle	

FHE After Sales Service & Support (AU)
 Phone: 1300887055
 Spares Email: spares@fedservices.com.au

FHE After Sales Service & Support (NZ)
 Phone: 09 415 6471
 Service Email: service@fedproducts.co.nz

SN-128F PARTS LIST

Item		FHE Part Code	Description	Remark
17*		08.1.0026-00	Evaporation Sensor with Black Soft Probe	
18		04.0.0102-00	Left slide of Door-41	
19		04.0.0103-00	Right slide of Door-41	
		06.3.0241-00	Evaporator Assembly	
		07.0.0072-00	Ice Stirring Blade	
		08.0.0135-00	PCB Board PC-507	
		13.2.0004-00	Evaporator Lower Base	
		13.2.0011-00	Mechanical Seal Group	

*Wearable Parts

FHE After Sales Service & Support (AU)
Phone: 1300887055
Spares Email: spares@fedservices.com.au

FHE After Sales Service & Support (NZ)
Phone: 09 415 6471
Service Email: service@fedproducts.co.nz